

Fig. | Block Diagram of Tree System




Fig. 2 Frequency Band Splitting




Fig. 3 Complex Down-Converter (CDC)




Fig. 4 Complex Up-Converter (CUC)




Figure S Block Diagram of Interleaved System





Figure 6 Detail of Interleavers



7 BASIC CDC(A) ARCHITECTURE Fig.

.

Multiplier





Fig. S BASIC CUC(A) ARCHITECTURE

Local Oscillator Frequency = Fs/4



A MODIFIED CDC(A) ARCHITECTURE Fig.






Fig. | MODIFIED CUC(A) ARCHITECTURE



|| COMBINED CDC(A) & CUC(A) ARCHITECTURE Fig.



 $C_{udd} = 0$, kQ_{d2} , Q_{d3} , kQ_{d4} , 0, $-kQ_{d6}$, $-Q_{d7}$, $-kQ_{d8}$... $C_{even} = 0$, kQ_{u2} , Q_{u3} , kQ_{u4} , 0, $-kQ_{u6}$, $-Q_{u7}$, $-kQ_{u8}$.

Fig. 12 BASIC ICDC(B) ARCHITECTURE




Fig. (2) BASIC ICUC(B) ARCHITECTURE

Deven = Qui, kQu2, 0, -kQu4, -Qu5, -kQu6, 0, kQu8 .

D. ad = Qa1, kQa2, 0, -kQa4, -Qa5, -kQa6, 0, kQa8 ..

Ceven = 0, kQu2, Qu3, kQu4, 0, -kQu6, -Qu7, -kQu8.

Codd = 0, kQd2, Qd3, kQd4, 0, -kQd6, -Qd7, -kQd8 ..

Figure 14 Simplified ICDC(B), I channel Only

0, 0, Qas, Qus, Qat, Qut, -Qato, -Qut

LO = -1, -1, 1, 1, 1, 1, -1, -1,




Figure (Simplified ICDC(B), Q channel Only




Figure 16 Simplified ICDC(B), Combined I & Q Channels




Figure 17 Simplified ICUC(B), Combined I & Q Channels




Fig. 18 BASIC ICDC(C) ARCHITECTURE

D (3,4)

Figure 19 Simplified ICDC(C), Combined I & Q Channels




Figure 20 Combined ICDC(B) / ICUC(B) With Polyphase Filters